BESSEY® Product Training





BESSEY® Tools North America Flooring Tool: AV2 Spacer

AV2 Spacer – Compact and time-saving flooring aid



Clever dail:


Set up is fast and simple: Distance to the wall can be set simply by turning the red dail.


The spacer is easy to remove just, rotate the dial to release the pressure.

2 Wide contact and support surface:

> For avoiding pressure points on the wall and the flooring.









- Wall surface irregularities of 5 to 20 mm can be compensated for easily.
- The exact distance required for spacing can be readily seen on the millimetre scale.



- Manufactured from impact and break resistant, glass fibre reinforced polyamide
- the spacer is light and tough.







AV2 Spacer – Compact and time-saving flooring aid







AV2 Spacer – Compact and time-saving flooring aid









Thank you for your attention!

BESSEY® Tools North America



